

ColorPro 4.4 Windows 8 Install Instructions

Prior to installing ColorPro

- Make sure the current user has **full admin rights**.
- Turn the UAC (user account control) completely off
- Set the screen resolution to 1024x768

Install Process

1. Install CP4.4 – this process takes about 15 minutes.
2. Install SW1720 (C) – This is the FFM IDD (for X-Smart dispensers only)
3. Install the machine configuration
4. Install database
5. Install SW1681 firmware

Special Permissions

6. Explore the C:\ drive
7. On 64-bit PC's: Right-click on the **Program Files (x86)** folder, click on **properties**
On 32-bit PC's: Right-click on the **Program Files** folder, click on **properties**
8. Click on the **Security** tab
9. Click on **Advanced** button
10. If the Owner listed is the current user, **skip to step #.**
11. If the Owner listed is not the current user, click **Change**
12. Click on the **Advanced** button
13. Click **Find Now** button, all the users should now appear.
14. Find the current user and **double-click their name**
15. Click the **OK** button
16. **Check the Replace owner on subcontainers and objects** box
17. **Click Apply** button
The Owner will now be the current user.

If any of these permission steps fail, you do not have full admin rights for the user. Contact your IT administrator.

Running ColorPro

18. Navigate to **C:\Program Files (x86)\Fluid Management\IDDdvx\FTDI_CDM v2.08.28 Certified**
19. Right-click on **dp-chooser.exe** and select **Run as administrator** – This will allow for the driver to be installed correctly and establish a com port
20. Close all windows and return to the desktop
21. Right-click on Colorpro and select **Run as administrator** – this will allow the program to open normally any time the icon is used.